



**EtherNet/IP**

**C2P-EI Series Bus Valve Terminal**

**User Manual**



Nanjing Solidot Electronic Technology Co., Ltd. 2024

**Copyright © Nanjing Solidot Electronic Technology Co., Ltd. 2024. All rights reserved .**

Without the written permission of our company, no unit or individual may excerpt or copy part or all of the contents of this document, or disseminate it in any form.

### **Trademark Statement**

 and other Solidot trademarks are trademarks of Nanjing Solidot Electronic Technology Co., Ltd.

All other trademarks or registered trademarks mentioned in this document are the property of their respective owners.

### **Notice**

The products, services or features you purchase shall be subject to the commercial contracts and terms of Real Point Company. All or part of the products, services or features described in this document may not be within the scope of your purchase or use. Unless otherwise agreed in the contract, Solidot Company does not make any express or implied representations or warranties regarding the contents of this document.

Due to product version upgrades or other reasons, the content of this document will be updated from time to time. Unless otherwise agreed, this document is only a guide for use, and all Statusments, information and suggestions in this document do not constitute any express or implied warranty.

Nanjing Solidot Electronic Technology Co., Ltd.

11th Floor, Angying Building, No. 91 Shengli Road, Jiangning District, Nanjing City, Jiangsu Province

Postcode: 21 1106

Phone: 4007788929

Website: <http://www.solidotech.com>

# CONTENTS

|   |    |
|---|----|
| 1 Product Introduction .....                                      | 1  |
| 1.1 Product overview .....  | 1  |
| 1.2 Product Characteristics .....                                 | 1  |
| 2 Designation Rules .....   | 3  |
| 2.1 Designation Rules .....                                       | 3  |
| 2.2 Model List .....  | 4  |
| 3 Product Parameters .....  | 5  |
| 3.1 General parameter .....                                       | 5  |
| 4 Panel .....   | 7  |
| 4.1 Product Structure .....                                       | 7  |
| 4.2 Indicator light function .....                                | 8  |
| 4.3 Rotary Switch .....   | 9  |
| 5 mounting .....  | 11 |
| 5.1 External Dimensions .....                                     | 11 |
| 5.2 Solenoid valve installation sequence .....                    | 13 |
| 6 Wiring .....  | 14 |
| 6.1 Solenoid valve wiring .....                                   | 14 |
| 6.2 Power Supply Wiring .....                                     | 18 |
| 6.3 Bus Wiring .....  | 19 |
| 7 Operation .....   | 20 |
| 7.1 Control Method .....  | 20 |
| 7.2 Diagnostic Function .....                                     | 22 |
| 7.3 IP settings and modifications .....                           | 24 |
| 7.3.1 Setting the IP address by rotary switch .....               | 24 |
| 7.3.2 Setting the IP address via the host computer software ..... | 25 |
| 7.3.3 Setting an IP address with the IP Setting Tool .....        | 26 |
| 7.4 Restore Factory Settings .....                                | 27 |
| 7.5 Parameter description .....                                   | 28 |
| 7.5.1 Output signal clear/hold function .....                     | 28 |
| 7.6 Configuration Applications .....                              | 29 |


---

|   |    |
|---|----|
| 7.6.1 Application in KV STUDIO software environment.....    | 29 |
| 7.6.2 Application in CODESYS V3.5 software environment..... | 46 |
| 8 FAQ.....  | 57 |
| 8.1 Unable to scan to module.....                           | 57 |
| 8.2 IP address assignment anomaly.....                      | 57 |
| 8.3 IP Setting Tool tool does not scan for devices.....     | 59 |

# 1 Product Introduction

## 1.1 Product overview

C2P-EI series valve terminal is a control module integrating valve terminal technology and EtherNet/IP bus technology, through which it can realize decentralized control and centralized control in industrial field, optimize system design, quick construction, and simplify debugging, performance testing and diagnostic maintenance of complex systems. The product adopts modular structure, occupies little space, the terminal is pluggable, can be quickly wired, simple configuration, supports all major mainstream EtherNet/IP master station, can be widely used in industrial control systems.



## 1.2 Product Characteristics

- Support EtherNet/IP industrial Ethernet protocols
- RJ45 bus interface, support cascade communication
- Maximum support for 24-position dual-control solenoid valves
- Modular structure, small footprint
- Simple wiring, quick construction and easy maintenance
- Support customization, support mainstream solenoid valves, simple and fast selection

- Supports remote diagnosis to reduce troubleshooting difficulties

# 2 Designation Rules

## 2.1 Designation Rules

**C2P** - **EI** - **24** **B** - **F01**  
**(1)**      **(2)**      **(3)** **(4)**      **(5)**

| Number | Meaning                            | Description of values  |             |             |             |             |
|--------|------------------------------------|--|-------------|-------------|-------------|-------------|
| (1)    | Product Type                       | C2P (RJ45 connector)   |             |             |             |             |
| (2)    | Bus protocol                       | EI: Abbreviation for EtherNet/IP Protocol                          |             |             |             |             |
| (3)    | Number of Solenoid Valve Positions | 08: 8-bit  | 12: 12 bits | 16: 16 bits | 20: 20 bits | 24: 24 bits |
| (4)    | Type of electric control           | B: Dual electric control (compatible with single electric control) |             |             |             |             |
| (5)    | Solenoid Valve Model Code          | See <a href="#">solenoid valve model code table</a> below          |             |             |             |             |

**Solenoid Valve Model Code List :**

| Brand  | Code | Valve spacing | Range     | Supported Solenoid Valve Models                              |
|--------|------|---------------|-----------|--|
| AirTAC | A01  | 19            | 4V1       | 4V110/ 4V120/ 4V130  |
|        | A02  | 23            | 4V2       | 4V210/ 4V220/ 4V230  |
|        | A04  | 10.5          | 7V0       | 7V0510/ 7V0520/ 7V0530                                       |
|        | A05  | 16            | 7V1       | 7V110/ 7V120/ 7V130  |
|        | A06  | 19            | 7V2       | 7V210/ 7V220/ 7V230  |
|        | A07  | 19            | 5V1       | 5V110/ 5V120/ 5V130  |
|        | A08  | 23            | 5V2       | 5V210/ 5V220/ 5V230  |
| FESTO  | F01  | 10.5          | VUUG-LK10 | vuvg-lk10-t32/ vuvg-lk10-m52<br>vuvg-lk10-B52/ vuvg-lk10-p52 |
|        |      |               | VUUG-L10  | vuvg-l10-t32/ vuvg-l10-m52<br>vuvg-l10-B52/ vuvg-l10-p52     |
|        | F02  | 16            | VUUG-LK14 | vuvg-lk14-t32/ vuvg-lk14-m52<br>vuvg-lk14-B52/ vuvg-lk14-p52 |
|        |      |               | VUUG-L14  | vuvg-l14-t32/ vuvg-l14-m52<br>vuvg-l14-B52/ vuvg-l14-p52     |
| SMC    | S01  | 10.5          | SY3       | SY3120/ SY3220/ SY3320<br>SY3420/ SY3520                     |
|        | S02  | 16            | SY5       | SY5120/ SY5220/ SY5320<br>SY5420/ SY5520                     |
|        | S03  | 19            | SY7       | SY7120/ SY7220/ SY7320/<br>SY7420/ SY7520                    |
| CKD    | C01  | 10.5          | 4GD1      | 4gd119r/ 4gd129r/ 4gd139r<br>4GD149R/ 4GD159R                |
|        | C02  | 16            | 4GD2      | 4gd219r/ 4gd229r/ 4gd239r<br>4GD249R/ 4GD259R                |

Note: Valve spacing (K value) unit: mm.

**2.2 Model List**

| Model number  | Product Description                     |
|---------------|---|
| C2P-EI-08B-() | 8-position dual control solenoid valve  |
| C2P-EI-12B-() | 12-position dual control solenoid valve |
| C2P-EI-16B-() | 16-position dual-control solenoid valve |
| C2P-EI-20B-() | 20-position dual control solenoid valve |
| C2P-EI-24B-() | 24-position dual-control solenoid valve |

Note: () brackets represent solenoid valve model code, support self-selected customization.

# 3 Product Parameters

## 3.1 General parameter


| <b>Interface parameter</b>                    |  |
|---|--|
| Bus protocol                                  | EtherNet/IP                              |
| Data transmission medium                      | Category 5+ UTP or STP (STP recommended) |
| Transmission distance                         | ≤100 m (station to station)              |
| Transmission rate                             | 100 Mbps                                 |
| Bus interface                                 | 2◇RJ45                                   |
| <b>Technical Parameters</b>                   |  |
| System power supply                           | 24 VDC (18V~30V)                         |
| Rated current consumption                     | 30 mA                                    |
| Electrical isolation                          | 500 VAC                                  |
| Load power                                    | 24 VDC (18V~30V)                         |
| Output points                                 | 0~48                                     |
| Single channel current                        | Max: 250 mA                              |
| Power connection method                       | 5Pin Pop-Up Terminal Block               |
| Power interface surge protection              | Support                                  |
| Power connector reverse connection protection | Support                                  |
| Channel short circuit protection              | Support                                  |

|                                   |  |
|-----------------------------------|--|
| Channel open diagnostics          | Support  |
| Channel short circuit diagnostics | Support  |
| Weights                           | Varies by product model  |
| Sizes                             | Differences by product model (see <a href="#">5.1 External Dimensions</a> for details) |
| Operating temperature             | -5°C~+50°C   |
| Storage temperature               | -20°C~+75°C  |
| Relative humidity                 | 95%, non-condensing  |
| Ingress protection                | IP20   |

# 4 Panel

## 4.1 Product Structure

### Name and function description of each part of the product



| Number | Name                         | Description   |
|--------|------------------------------|---|
| ①      | Solenoids                    | See " <a href="#">Solenoid Valve Model Code List</a> " for details. |
| ②      | LED indicator                | Indicates power, operation and bus status                           |
| ③      | Power connector              | 5Pin Pop-Up Terminal Block  |
| ④      | Bus interface                | RJ45, Bus OUT Interface   |
| ⑤      | Power connector              | RJ45, Bus IN Interface  |
| ⑥      | Rotary switch                | Setting IP address, reset settings                                  |
| ⑦      | An air vent                  | G1/4  |
| ⑧      | Air intake                   | G1/4  |
| ⑨      | Communications unit          | valve terminal Communication and Control Body                       |
| ⑩      | Solenoid valve wiring socket | 4Pin  |

|   |          |  |
|---|----------|--|
| ⑪ | Manifold | valve terminal body with A and B silkscreen on both ends |
|---|----------|--|


## 4.2 Indicator light function

| Name                       | Markings | Color | Status   | Status Description   |
|----------------------------|----------|-------|----------|--|
| System power indicator     | US       | GREEN | ON       | Power supply normal  |
|                            |          |       | OFF      | The product is not powered up or the power supply is abnormal  |
| Load power indicator       | UL       | GREEN | ON       | Power supply normal  |
|                            |          |       | OFF      | The product is not powered up or the power supply is abnormal  |
| Network indicator IN       | L/A0     | GREEN | FLASHING | Network connection with data interaction   |
|                            |          |       | OFF      | No data interaction or exception   |
| Network indicator OUT      | L/A1     | GREEN | FLASHING | Network connection with data interaction   |
|                            |          |       | OFF      | No data interaction or exception   |
| Operation Status Indicator | RUN      | GREEN | ON       | The device has established a connection  |
|                            |          |       | FLASHING | 1Hz: the device has not established a connection but has acquired an IP address; the IP address is duplicated; the device is undergoing a power-up test. |
|                            |          |       | OFF      | The device has not been given an IP address; the device is in an unpowered state.  |
| Warning indicator          | ERR      | RED   | ON       | Valve is shorted/over-tempered or unit is being restored to factory settings   |
|                            |          |       | OFF      | System running normally or not powered up  |

## 4.3 Rotary Switch

### IP address setting

A rotary switch can be used to specify the setting method of the module IP address.



| Set value (decimal) | IP address setting method  |
|---------------------|--|
| 001 to 254          | Set the IP address in the range of 1 to 254 with "×100" for the hundredth digit, "×10" for the tenth digit, and "×1" for the first digit. Setting in the range of 1 to 254.<br>IP Address High 3Byte continuation of the value previously set via the host computer.<br>When the IP address is set to a value other than 000 by the rotary switch in the factory factory state, the high 3Byte is 192.168.0. |
| 000, 255-998        | When the rotary switch is set to 255 or 255 or more, the module powers up with the last startup method and parameter startup.  |
| 999                 | Reset Settings.  |

The factory rotary switch is set to "000".

#### Remarks:

##### 1、 Tool selection

**Screwdriver specifications: 2 mm opening.**

- 2、 The rotary switch IP must always be set in the event of a power failure. If the IP address needs to be changed during communication, the new setting must be re-powered after it is completed to take effect.

### Reset function


Restoration of factory settings can be executed by special operation of the rotary switch.

For details on how to do this, see: [7.4 Restore Factory Settings](#).

# 5 Installation

## 5.1 External Dimensions

### External size (unit mm)



Plug, muffler, port adapters: G1/4

| L size             |      |      |       |       |       |       |       |       |       |       |       |
|--------------------|------|------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| Number of position | 4    | 6    | 8     | 10    | 12    | 14    | 16    | 18    | 20    | 22    | 24    |
| <b>K=10.5</b>      | 59.5 | 80.5 | 101.5 | 122.5 | 143.5 | 164.5 | 185.5 | 206.5 | 227.5 | 248.5 | 269.5 |
| <b>K=16</b>        | 76   | 108  | 140   | 172   | 204   | 236   | 268   | 300   | 332   | 364   | 396   |
| <b>K=19</b>        | 88   | 126  | 164   | 202   | 240   | 278   | 316   | 354   | 392   | 430   | 468   |
| <b>K=23</b>        | 103  | 149  | 195   | 241   | 287   | 333   | 379   | 425   | 471   | 517   | 563   |

| <b>P size</b>             |          |          |          |           |           |           |           |           |           |           |           |
|---------------------------|----------|----------|----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|
| <b>Number of position</b> | <b>4</b> | <b>6</b> | <b>8</b> | <b>10</b> | <b>12</b> | <b>14</b> | <b>16</b> | <b>18</b> | <b>20</b> | <b>22</b> | <b>24</b> |
| <b>K=10.5</b>             | 136.5    | 157.5    | 178.5    | 199.5     | 220.5     | 241.5     | 262.5     | 283.5     | 304.5     | 325.5     | 346.5     |
| <b>K=16</b>               | 153      | 185      | 217      | 249       | 281       | 313       | 345       | 377       | 409       | 441       | 473       |
| <b>K=19</b>               | 165      | 203      | 241      | 279       | 317       | 355       | 393       | 431       | 469       | 507       | 545       |
| <b>K=23</b>               | 180      | 226      | 272      | 318       | 364       | 410       | 456       | 502       | 548       | 594       | 640       |

## 5.2 Solenoid valve installation sequence

- **Solenoid Valve for valve terminal**


For details of solenoid valves for Valve Terminal, see "[2.1 Naming Rules Solenoid Valve Model Code List](#)".

- **Solenoid valve installation sequence**

The solenoid valves are installed in order from the communication unit end.

Installation order for dual electronically controlled solenoid valve installation: Starting from the communication unit end, install the dual electronically controlled solenoid valve from the 1st position to the Nth position in sequence, and the installation order is shown in the figure below.

Installation order of single electronically controlled solenoid valve installation: Starting from the communication unit end, install single electronically controlled solenoid valves in order from position 1 to position N. Solenoid valve wiring can be done on the A side, and the installation order is shown in the following figure.




# 6 Wiring


## 6.1 Solenoid valve wiring

### Valve terminal Terminal Distribution

The valve terminal wiring terminals are distributed on both sides of the valve terminal manifold, respectively, side A and side B. Side A and side B can be distinguished according to the silkscreen on the end of the valve terminal manifold. Take valve terminal C2P-EI-24B-F02 as an example, the distribution of A-side and B-side terminals is shown in the figure below.



A-side solenoid valve terminal wiring terminal




B-side solenoid valve terminal wiring terminal

| Wiring terminal |               |                                   |
|-----------------|---------------|-----------------------------------|
| Terminals       | Extremity     | 4P                                |
|                 | Wire diameter | 22~17 AWG 0.3~1.0 mm <sup>2</sup> |

### Wiring Tool Requirements

The solenoid valve terminal adopts screw-free design, and the installation and removal of cables can be operated with a screwdriver (specification:  $\leq 2\text{mm}$ ).



### Stripped Wire Length Requirements

Recommended cable stripping length for solenoid valve terminals  
10 mm



### Wiring Method

For single stranded hard wires, after stripping the corresponding length of wire, press down the button while inserting the single stranded wire.



Multi-stranded flexible wires, after stripping the corresponding length of wire, can be directly connected or supporting the use of the corresponding standard specifications of the cold compression end (tube-type insulated terminal, the reference specifications are shown in the table below), press down the button at the same time the line will be inserted.




| Tube Insulation End Specification Sheet |       |   |
|---|-------|---|
| specification                           | Model | Cross-sectional area of conductor mm <sup>2</sup> |
|   | E0310 | 0.3   |
|   | E0510 | 0.5   |
|   | E7510 | 0.75  |

---

|  |       |     |
|--|-------|-----|
| Tube insulated terminal L with a length of 10 mm | E1010 | 1.0 |
|--|-------|-----|


● **Solenoid valve wiring**

For different types of Valve Terminal, 4Pin sockets with corresponding positions are configured on both sides of the manifold, and a set of "+" and "-" of the sockets can drive a solenoid valve coil. As shown in the figure below, A1 and A2 can drive one solenoid valve coil respectively.



● **Valve Terminal Wiring**

Starting from the communication unit end, the solenoid valve coils on the A and B sides of the manifold correspond one to the other, and the correspondence between the channels and the solenoid valve coils is shown in the figure below.



**Solenoid valve wiring principles:**

- Install the solenoid valve in accordance with "[5.2 Solenoid Valve Installation Sequence](#)".
- AX and BX can be connected to a dual electric solenoid valve, and AX can be connected to a single electric solenoid valve. For wiring, please strictly follow the table below, otherwise the solenoid valve will not work or misoperate. "✗" means no wiring.

| Dual control solenoid valve wiring (all valve pieces are dual control solenoid valves) |    |    |    |    |    |    |    |    |      |
|--|----|----|----|----|----|----|----|----|------|
| Terminals  | A1 | B1 | A2 | B2 | A3 | B3 | A4 | B4 | .... |
| Solenoid Valve No.   | 1  |    | 2  |    | 3  |    | 4  |    | .... |

|                    |       |     |     |     |     |     |     |
|--------------------|-------|-----|-----|-----|-----|-----|-----|
| Terminals          | ..... | A22 | B22 | A23 | B23 | A24 | B24 |
| Solenoid Valve No. | ..... | 22  |     | 23  |     | 24  |     |

Note: This example takes C2P-EI-24B-() valve terminal, 24-position dual-control solenoid valve as an example, the rest of the different specifications of the valve terminal, there are differences in wiring.



| Dual-control solenoid valve wiring (all access valve pieces are single-control solenoid valves) |    |    |    |    |    |    |    |    |      |
|---|----|----|----|----|----|----|----|----|------|
| Terminals   | A1 | B1 | A2 | B2 | A3 | B3 | A4 | B4 | .... |
| Solenoid Valve No.  | 1  | ✗  | 2  | ✗  | 3  | ✗  | 4  | ✗  | .... |

|                    |       |     |     |     |     |     |     |
|--------------------|-------|-----|-----|-----|-----|-----|-----|
| Terminals          | ..... | A22 | B22 | A23 | B23 | A24 | B24 |
| Solenoid Valve No. | ..... | 22  | ✗   | 23  | ✗   | 24  | ✗   |

Note: This example to C2P-EI-24B-() valve terminal, only access to the single-control solenoid valve as an example, the rest of the different specifications of the valve terminal, wiring differences.

## 6.2 Power Supply Wiring

Power supply terminal S indicates the system power supply, L indicates the load power supply, wiring method and solenoid valve wiring method is consistent with the silkscreen and power parameters can be wired against the power supply, power supply 5P terminal as shown in the following figure:





### ⚠ Precautions

- 
- The module system-side power supply and the field-side power supply are configured and used separately, so do not mix them.
  - PE needs to be reliably grounded.
- 

## 6.3 Bus Wiring

The bus interface uses an RJ45 connector as shown below:



### ⚠ Precautions

- 
- Adopt standard RJ45 network interface with standard crystal connector.
  - The length of the cables between the devices must not exceed 100 m.
-

# 7 Operation

## 7.1 Control Method

Valve terminal solenoid valve control byte way, a byte control 4 valves; at the same time can be controlled in accordance with the bit way, a group of 8 bits, control 1->8 channels, the channel value of 1 is the corresponding solenoid valve is open, the channel value of 0 is the corresponding solenoid valve is closed. 24-bit dual-control solenoid valves have a total of 6 groups of control bits, a total of 48 channel control. Take 24-position dual-control solenoid valve as an example to introduce the output control function of the valve terminal, the control mode is shown in the table below.

| Control method     | valve[1..4]      |                  |                  |                  |                  |                  |                  |                  |
|--------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|
| Channel address    | valve [1..4] [0] | valve [1..4] [1] | valve [1..4] [2] | valve [1..4] [3] | valve [1..4] [4] | valve [1..4] [5] | valve [1..4] [6] | valve [1..4] [7] |
| Transformers       | A1               | B1               | A2               | B2               | A3               | B3               | A4               | B4               |
| Solenoid Valve No. | 1                |                  | 2                |                  | 3                |                  | 4                |                  |

| Control method     | valve[5..8]      |                  |                  |                  |                  |                  |                  |                  |
|--------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|
| Channel address    | valve [5..8] [0] | valve [5..8] [1] | valve [5..8] [2] | valve [5..8] [3] | valve [5..8] [4] | valve [5..8] [5] | valve [5..8] [6] | valve [5..8] [7] |
| Transformers       | A5               | B5               | A6               | B6               | A7               | B7               | A8               | B8               |
| Solenoid Valve No. | 5                |                  | 6                |                  | 7                |                  | 8                |                  |

| Control method     | valve [9...12]     |                    |                    |                    |                    |                    |                    |                    |
|--------------------|--------------------|--------------------|--------------------|--------------------|--------------------|--------------------|--------------------|--------------------|
| Channel address    | valve [9...12] [0] | valve [9...12] [1] | valve [9...12] [2] | valve [9...12] [3] | valve [9...12] [4] | valve [9...12] [5] | valve [9...12] [6] | valve [9...12] [7] |
| Transformers       | A9                 | B9                 | A10                | B10                | A11                | B11                | A12                | B12                |
| Solenoid Valve No. | 9                  |                    | 10                 |                    | 11                 |                    | 12                 |                    |

| Control method     | valve [13...16]     |                     |                     |                     |                     |                     |                     |                     |
|--------------------|---------------------|---------------------|---------------------|---------------------|---------------------|---------------------|---------------------|---------------------|
| Channel address    | Valve [13...16] [0] | Valve [13...16] [1] | Valve [13...16] [2] | Valve [13...16] [3] | Valve [13...16] [4] | Valve [13...16] [5] | Valve [13...16] [6] | valve [13...16] [7] |
| Transformers       | A13                 | B13                 | A14                 | B14                 | A15                 | B15                 | A16                 | B16                 |
| Solenoid Valve No. | 13                  |                     | 14                  |                     | 15                  |                     | 16                  |                     |

| Control method     | valve[17..20]       |                     |                     |                     |                     |                     |                     |                     |
|--------------------|---------------------|---------------------|---------------------|---------------------|---------------------|---------------------|---------------------|---------------------|
| Channel address    | valve [17...20] [0] | valve [17...20] [1] | Valve [17...20] [2] | valve [17...20] [3] | valve [17...20] [4] | valve [17...20] [5] | valve [17...20] [6] | valve [17...20] [7] |
| Transformers       | A17                 | B17                 | A18                 | B18                 | A19                 | B19                 | A20                 | B20                 |
| Solenoid Valve No. | 17                  |                     | 18                  |                     | 19                  |                     | 20                  |                     |

| Control method     | valve [21...24]     |                     |                     |                     |                     |                     |                     |                     |
|--------------------|---------------------|---------------------|---------------------|---------------------|---------------------|---------------------|---------------------|---------------------|
| Channel address    | valve [21...24] [0] | valve [21...24] [1] | valve [21...24] [2] | valve [21...24] [3] | valve [21...24] [4] | valve [21...24] [5] | valve [21...24] [6] | valve [21...24] [7] |
| Transformers       | A21                 | B21                 | A22                 | B22                 | A23                 | B23                 | A24                 | B24                 |
| Solenoid Valve No. | 21                  |                     | 22                  |                     | 23                  |                     | 24                  |                     |

## 7.2 Diagnostic Function

The C2P-EI valve terminal has an open circuit diagnostic (Open load) and a short circuit or overtemperature diagnostic (Short circuit or overtemperature). An open circuit can only be monitored if the valve is closed and a short circuit can only be monitored if the valve is open.

The diagnostic function is the same as the control mode, and also sends diagnostic information in Byte or bit. If the valve is closed, the diagnostic message Open load is normal if the value is 0, and 1 means the corresponding valve is open. Under the premise of valve opening, valve short circuit or overtemperature diagnostic information Short circuit or overtemperature value is 0 is normal, 1 represents the corresponding valve short circuit/overtemperature.

The channel diagnostic information and solenoid valve correspondence for Open load and Short circuit or overtemperature diagnostics are the same, taking Open load diagnostics as an example, the correspondence is shown in the table below.

| Diagnostic function | Open load[0..7] |                |                 |                 |                 |                 |                |                |
|---------------------|-----------------|----------------|-----------------|-----------------|-----------------|-----------------|----------------|----------------|
| Channel address     | Open [0..7] [0] | Open[0..7] [1] | Open [0..7] [2] | Open [0..7] [3] | Open [0..7] [4] | Open [0..7] [5] | Open[0..7] [6] | Open[0..7] [7] |
| Transformers        | A1              | B1             | A2              | B2              | A3              | B3              | A4             | B4             |
| Solenoid Valve No.  | 1               |                | 2               |                 | 3               |                 | 4              |                |

Note: Open load is abbreviated as Open in the table, below.

| Diagnostic function | Open load[8..15] |                  |                  |                  |                  |                  |                  |                  |
|---------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|
| Channel address     | Open [8..15] [0] | Open [8..15] [1] | Open [8..15] [2] | Open [8..15] [3] | Open [8..15] [4] | Open [8..15] [5] | Open [8..15] [6] | Open [8..15] [7] |
| Transformers        | A5               | B5               | A6               | B6               | A7               | B7               | A8               | B8               |
| Solenoid Valve No.  | 5                |                  | 6                |                  | 7                |                  | 8                |                  |

| Diagnostic function | Open load[16..23] |                    |                    |                    |                    |                    |                    |                    |
|---------------------|-------------------|--------------------|--------------------|--------------------|--------------------|--------------------|--------------------|--------------------|
| Channel address     | Open [16..23] [0] | Open [16...23] [1] | Open [16...23] [2] | Open [16...23] [3] | Open [16...23] [4] | Open [16...23] [5] | Open [16...23] [6] | Open [16...23] [7] |
| Transformers        | A9                | B9                 | A10                | B10                | A11                | B11                | A12                | B12                |
| Solenoid Valve No.  | 9                 |                    | 10                 |                    | 11                 |                    | 12                 |                    |

| Diagnostic function | Open load[24..31]    |                      |                      |                      |                      |                      |                      |                      |
|---------------------|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|
| Channel address     | Open [24..31]<br>[0] | Open [24..31]<br>[1] | Open [24..31]<br>[2] | Open [24..31]<br>[3] | Open [24..31]<br>[4] | Open [24..31]<br>[5] | Open [24..31]<br>[6] | Open [24..31]<br>[7] |
| Transformers        | A13                  | B13                  | A14                  | B14                  | A15                  | B15                  | A16                  | B16                  |
| Solenoid Valve No.  | 13                   |                      | 14                   |                      | 15                   |                      | 16                   |                      |

| Diagnostic function | Open load [32..39]   |                      |                      |                      |                      |                      |                      |                      |
|---------------------|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|
| Channel address     | Open [32..39]<br>[0] | Open [32..39]<br>[1] | Open [32..39]<br>[2] | Open [32..39]<br>[3] | Open [32..39]<br>[4] | Open [32..39]<br>[5] | Open [32..39]<br>[6] | Open [32..39]<br>[7] |
| Transformers        | A17                  | B17                  | A18                  | B18                  | A19                  | B19                  | A20                  | B20                  |
| Solenoid Valve No.  | 17                   |                      | 18                   |                      | 19                   |                      | 20                   |                      |

| Diagnostic function | Open load[40..47]    |                      |                      |                      |                      |                      |                      |                      |
|---------------------|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|
| Channel address     | Open [40..47]<br>[0] | Open [40..47]<br>[1] | Open [40..47]<br>[2] | Open [40..47]<br>[3] | Open [40..47]<br>[4] | Open [40..47]<br>[5] | Open [40..47]<br>[6] | Open [40..47]<br>[7] |
| Transformers        | A21                  | B21                  | A22                  | B22                  | A23                  | B23                  | A24                  | B24                  |
| Solenoid Valve No.  | 21                   |                      | 22                   |                      | 23                   |                      | 24                   |                      |

## 7.3 IP settings and modifications

### 7.3.1 Setting the IP address by rotary switch

➤ **When the IP address is set by the rotary switch in the factory state**

IP address is 192.168.0.XXX (XXX is the setting value of the rotary switch, range 1~254).

➤ **When setting the IP address with the rotary switch in a state where the IP address has already been set by the host computer**

The IP address follows the high 3byte and the low 1byte of the IP address set via the host computer as the setting value of the rotary switch.

For example, when changing the setting of the rotary switch after setting it to 172.10.0.12 via the upper unit, the IP address is 172.10.0.XXX (XXX is the setting value of the rotary switch (1 to 254)).


#### Precautions

- For the description and operation of the rotary switch, see "[4.3 Rotary Switch](#)".
- When the module is shipped from the factory, the rotary switch is set to "000" and the IP address defaults to 192.168.0.120.
- After the modification by the host computer is completed, the module modifies the startup method to fixed IP startup and reboots automatically. The module starts with the IP address consisting of the rotary switch setting value and the assigned network segment.
- Abnormal rotary switch setting: When the rotary switch is set to 255 or 255 or more, the module starts in the same way as the previous startup with parameters after powering up.

### 7.3.2 Setting the IP address via the host computer software

This section describes how to change the IP address, using the Keyence KV-7500 and the host computer KV STUDIO Ver.10G as an example.

- a. After finding the device, click the IP address on the corresponding device to modify the IP address, and select "Fixed IP Start" as the IP address setting method. Click the "OK" button after the modification is completed, as shown in the figure below.




#### Precautions

- If you use BOOTP to modify the IP address, you need to set the timeout between the request acceptance time during scanning and the timeout time when the IP address is set to 60s or more, and you need to set the module to start with a fixed IP after the modification is completed, otherwise the assigned IP address will be lost after the power is turned off.

### 7.3.3 Setting an IP address with the IP Setting Tool

After the device is powered on, wait for 15s and the device will complete the network service startup. After that, the first scan will be performed by the IP Setting Tool tool to set the IP address.

1. Open the IP Setting Tool and click the "Scan EtherNet/IP Devices" button.




2. Set the IP segment and click "OK" .



The scanned devices, as shown in the following figure.



3. Double-click the device and set the IP address in the pop-up "Setup IP addr." window, as shown below.



## 7.4 Restore Factory Settings

If the IP address is forgotten, lost or other abnormalities occur during use, the module can be reset by the IP address reset function to the module. The module can execute the operation of restoring factory settings through the special operation of the rotary switch as follows:

- Scenario 1 The device has been powered on to perform a factory reset while in use
  - 1) Set the rotary switch to 999 and wait for 2s, at this time the ERR indicator lights up and the module automatically performs the restoration of factory settings;
  - 2) After the module is restored to factory settings, the IP address parameter is cleared and the startup mode is BOOTP;
  - 3) ① Set the rotary switch to 000, 255 or 255 or more (except 999), and the IP address will be restored to the factory address, i.e. 192.168.0.120, after re-powering up.
    - ② Set the rotary switch to 001~254, and after re-powering up, the IP address is 192.168.0.XXX (XXX is the setting value of the rotary switch, range 1~254).
- Scenario 2 The device performs a factory reset in the event of a power failure
  - 1) Set the rotary switch to 999 and power up the module, the module will automatically perform the restoration of factory settings;
  - 2) After the module is restored to factory settings, the IP address parameter is cleared and the startup mode is BOOTP;
  - 3) ① Set the rotary switch to 000, 255 or 255 or more (except 999), and the IP address will be restored to the factory address i.e. 192.168.0.120 after re-powering up.
    - ② Set the rotary switch to 001~254, and after re-powering up, the IP address is 192.168.0.XXX (XXX is the setting value of the rotary switch, range 1~254).

## 7.5 Parameter description

### 7.5.1 Output signal clear/hold function

The Clear/Hold function is for the output signal of the valve terminal, and this function can configure the output action of the valve terminal in the abnormal state of the bus.

**Clear Output:** When communication is disconnected, the valve terminal output channel automatically clears the output.

**Hold Output:** The valve terminal output channel keeps on outputting when communication is disconnected.

The function supports full-channel setting, single-channel setting and 8-channel batch setting grouped by driver chip, which can better meet the actual use requirements.

This manual takes KV STUDIO Ver.10G as an example to introduce the parameter configuration method, the specific steps are detailed in [7.6.1 Parameter Setting](#).

## 7.6 Configuration Applications

### 7.6.1 Application in KV STUDIO software environment

#### 1、 Preliminary

- **Hardware environment**

- **Valve terminal Model C2P-EI-24B**
- **A computer with KV STUDIO Ver.10G software pre-installed**
- **Shielded cable for valve terminal**
- **One Keyence PLC, KV-7500 is used as an example for this description.**
- **One switching power supply**
- **Device Configuration Files**

Configuration file access: <https://www.solidotech.com/documents/configfile>


**Note:** valve terminal configuration files with a high number of solenoid positions are compatible for valve Terminal with a lower number of solenoid positions, e.g., a C2P-EI-20B valve terminal can use a C2P-EI-24B configuration file, and so on.

- **Hardware configuration and wiring**

Please follow "[5 Installation](#)" and "[6 Wiring](#)".


#### 2、 Create Project

- Open KV STUDIO software, select "File -> New Project".
- In the pop-up box, fill in the "Item Name", select "PLC Models", "Position", as shown in the figure below.



- ◆ Project name: Customize.
- ◆ Supported models: View the PLC appearance and select the corresponding model, e.g. KV-7500.

- c. The "Confirm Unit Setting Information" window pops up, and you can select to start the Unit Editor, close the dialog box, or read the unit configuration from the PLC as necessary. Select "No" to demonstrate the operation, as shown in the figure below.




### 3. Communication settings


Select the communication method, if the PLC and the host computer software are connected through a network cable, select "Ethernet", if connected through USB, select "USB".

#### Procedure for "Ethernet" operation


- a. Click the button  on the menu bar to display the "Communication settings" window as shown below.



- b. Select "Ethernet", click "Destinations", select "1 sample", configure the IP address, and click "Search destination". Click "Search destination", as shown in the following figure, the IP address is configured in the "192.168.0" network segment.



- c. In the search destination pop-up window, select the network card and click "Execute", as shown in the following figure.



- d. Select the found PLC and click "Select" as shown in the following figure.

Search destination

Select network card

Network card (N) Realtek PCIe GbE Family Controller

IP address 192.168.0.222

Subnet mask 255.255.255.0

Port No. (P) 8500 Execute(S) Stop(B) Search in progress

Find Ethernet unit where broadcast packets reach. (KV only)  
\*Network load may increase according to the number of connected units.

Result

| MAC address       | Connected Unit type | IP address   | Project name |
|-------------------|---------------------|--------------|--------------|
| 00-01-7c-24-98-74 | KV-7500             | 192.168.0.10 | EC           |

Select Cancel


- e. Click the "OK" button on the Communication Settings window.

### "USB connection" operation method

Select USB in the "Communication Settings" interface .


### 4. EtherNet/IP settings

- a. Double click "Unit Configuration -> KV-7500 -> EtherNet/IP R30000 DMI10000" in the left navigation tree to bring up the "EtherNet/IP Settings" window. Select "Manual" or "Auto Configuration" as required. Select "Manual" to demonstrate the operation as shown in the figure below. When the setting is completed, click "OK" to close the window.




### 5. Installation of EDS files


- a. Right-click on the KV-7500 in the Unit Editor window and select "EtherNet/IP Settings" to enter the settings page as shown below.



- b. Click "EDS File" in the menu bar of the "EtherNet/IP Settings" screen, and then click "Register" as shown in the following figure.




- c. In the folder where the EDS file is placed, select the EDS file of the corresponding model and click "OK", the configuration file installation is completed, as shown in the following figure.




## 6. Topological configuration

Topology configuration can be "manually added" and "automatic configuration", this configuration using manual configuration.


- a. Enter the "EtherNet/IP Settings" page and switch to the "Search unit" tab, as shown in the following figure.




- b. Click , select the communication path, and the USB connection method is shown in the following figure.




- c. "PC Ethernet port direct link" is the network cable connection method, as shown in the following figure.




- d. Select "PC Ethernet port direct link" to bring up the "Select network card" window, and set the local network card and IP address, as shown in the following figure.




- e. Click  to search for devices connected to the network. Set the IP address segment for searching, and click "Search" as shown in the following figure.



- f. When the search is complete, the display is shown below.



- g. Double-click on the found device to add it to the configuration, as shown below.



## 7. Setting the IP address

In the interface of the found device, double-click the IP address column and configure the IP address in the pop-up box. The default address network segment is 192.168.0.


Description:

- The timeout for setting the IP address needs to be configured to 60s.
- If the dipswitch has been configured with an IP address, the IP of the dipswitch takes precedence.


The C2P-EI-24B in this example uses the default IP address of 192.168.0.120.

### 8. Parameter settings


- a. Click the Switch Mode option in the menu bar to switch to Editor mode, as shown in the following figure.




- b. Enter the "EtherNet/IP Settings" screen and click "Exclusive Owner" to bring up the "Connection Settings" window. In the "Connection Settings" window, click "Setup Parameter" as shown below.




- c. In the "Setup Parameter" window, you can configure the parameters of the valve terminal, and the parameters of the valve terminal of C2P-EI series are the output signal clear/hold setting function, as shown in the following figure.



- d. Output signal clear/hold parameter function, double click "BusFault Clear/Hold" option behind the set value, write **0** for clear, write **1** for hold; write **2** for single-channel setup or group setup, set the value of **2**, the following 0020~0025 parameters are valid, as shown in the figure below. Click "OK" to save the parameter, click "Apply" in the "EtherNet/IP Settings" window and download it to the controller to make the parameter take effect.



- e. Output signal clear/hold parameter function, 0001 "BusFault Clear/Hold" is set to **2**, modify the setting value of the group parameter of 0020~0025 below, and you can set clear/hold by channel, as shown in the following figure. Click "OK" to save the parameter, click "Apply" in the "EtherNet/IP Settings" window and download it to the controller to make the parameter take effect.




- f. When the configuration is complete, click the "OK" button in the "Setup Parameter" window.
- g. In the "Connection Settings" window, click the "OK" button.
- h. In the "EtherNet/IP Settings" window, click the "Apply" button and click the "OK" button.
- i. In the "Unit Editor" window, click the "Apply" button and click the "OK" button.


### 9、 Configuration Download

After module configuration and parameter setting are completed, download to PLC operation is performed.


- a. Click "Monitor/Simulator (N) -> Transfer to PLC -> Monitor Mode (C)" in the menu bar as shown below.




- b. The "Transfer Program" window pops up, check "Clear Program in PLC", click "Select All", click "Execute" to download the program to the PLC, as shown in the following figure.




- c. A prompt box pops up "Change to PROGRAM mode and overwrite? Continue?", click to select "Yes" as shown below.



- d. After writing to the PLC is completed, a pop-up box will appear, "Change to RUN mode", click and select "Yes", as shown in the figure below, to enter the monitoring mode.




- e. After the configuration is downloaded, it is shown in the following figure.




### 10、 Data monitoring

- a. In monitor mode, double click "C2P-EI-24B" icon to open the monitor table, you can monitor the module as shown below.




W00~W02 are the monitoring values for the open load function of the valve terminal.  
 W03~W05 are the monitoring values of valve terminal short circuit or overtemperature function.  
 W06~W08 for valve terminal output control function

- b. To turn on any of the solenoid coil outputs of the valve terminal, take the first channel as an example, you can double-click on the current value of W06 and enter 1 to turn on the first solenoid coil channel, as shown below.



- c. If you need to control a group of solenoid valve coil outputs, take the first group of channels as an example, you can double-click the current value of W06 to enter **255** to turn on the first group of solenoid valve coil channels, as shown in the following figure.



## 7.6.2 Application in CODESYS V3.5 software environment

### 1、 Preliminary

- **Hardware environment**

- **Valve terminal model C2P-EI-24B**
- **One computer, pre-installed with CODESYS V3.5 software**
- **Shielded cable for valve terminal**
- **One switching power supply**
- **Device configuration files**

Configuration file access: <https://www.solidotech.com/documents/configfile>


**Note:** valve terminal profiles with a high number of solenoid positions are compatible for use with Valve Terminal with a lower number of solenoid positions, e.g., a C2P-EI-20B valve terminal can use a C2P-EI-24B profile, and so on.

- **Hardware configuration and wiring**

Please follow "[5 Installation](#)" and "[6 Wiring](#)".


### 2、 Installation Profiles

- a. Open CODESYS software and select "Tools -> Device Repository" to install the EhterNet/IP EDS device description file.
- b. The Device Repository window pops up, click "Install", select the relevant EDS file to install. Successful installation shows that the device "xxxx" has been installed to the device repository, as shown in the following figure.




### 3. New construction

- a. Click "File", select "New Project", enter the project name, click "OK", as shown below.




### 4. Add "Ethernet"


- a. Start the PLC with "CODESYS Control Win V3 - x64 SysTray".
- b. Double-click "Device (CODESYS Control Win V3 X64)" in the left navigation tree, and click "Scan Network".
- c. Select Devices, Scan Network, and Network is active, as shown in the following figure.



- d. Right click on "Device(CODESYS Control Win V3 X64) " in the left navigation tree and select "Add Device".
- e. The Add Device window pops up, select "EthernetIP -> Ethernet Adapter -> Ethernet", click "Add Device", as shown in the following figure.




- f. Right-click "Ethernet" in the left navigation tree and select "Add Device".
- g. Select "EthernetIP -> EthernetIP Scanner -> Ethernet/IP Scanner" and click "Add Device" as shown in the following figure.




### 5. Configure "EthernetIP"

- a. Double-click on "Ethernet" in the left navigation tree to open the configuration window.
- b. In the General tab, click  to the right of Interfaces, select "Network Adapters", and finally click "OK", as shown in the following figure.




### 6. Add Device

- a. Click  to log in to the device.
- b. Right-click on "EtherNet\_IP\_Scanner (EtherNet/IP Scanner)" in the left navigation tree and select "Scan Devices".
- c. After scanning, select "C2P-EI-24B" and click "Copy to Project" as shown in the following figure.




d. The device has been added, as shown below.




## 7. Parameter settings

The parameter setting function is used to configure the clear/hold function of the valve terminal.


a. Double-click the device to open the "Device Configuration" window, switch to the "Connections" page, as shown below.




- b. Output signal clear/hold parameter function, click the drop-down menu behind the "BusFault Clear/Hold" option, select Clear for clear, select Hold for hold; select Set by Channel for single channel setting or group setting, at this time, the following Clear/Hold[0..7] ~ Clear/Hold[40..47] parameters are valid, as shown in the figure below. Hold[0..7] ~ Clear/Hold[40..47] parameters are valid, as shown below.




- c. "BusFault Clear/Hold" select Set by Channel, modify the value of the grouping parameter of Clear/Hold [0..7] below, you can set clear/hold by channel, as shown in the following figure.




d. Click "Online -> Multi-Download" in the menu bar, as shown below.



e. Multiple download window will pop up, select "Always perform a full download", click "OK", as shown in the figure below.




- f. Once the download is complete, click  and the system is online as shown below.




### 8. Data monitoring

- a. Click the  button to log out and switch to the "EtherNet/IP I/O Mapping" tab.
- b. Select "Enable 1" mode from the drop-down list in the lower right corner, as shown below.




c. Click  to log in and monitor the page as shown below.



- **Open circuit diagnostics** Open load[0..7], Open load[8..15], Open load[16..23], Open load[24..31], Open load[32..39], Open load[40..47], 48 channels can be diagnosed independently.
  - **Short circuit/overtemperature diagnosis** Short circuit or overtemperature[0..7], Short circuit or overtemperature[8..15], Short circuit or overtemperature[16..23], Short circuit or overtemperature[24..31], Short circuit or overtemperature[32..39], Short circuit or overtemperature[40..47], 48 channels can be diagnosed independently.
  - **Valve terminal output control function**, 24-bit dual-control solenoid valve, according to the driver chip grouping, a total of 6 groups of channels, valve[1..4], valve[5..8], valve[9..12], valve[13..16], valve[17..20], valve[21..24], each group of 8 channels, a total of 48 channel output control.
- d. **Open diagnostic Open load**, a diagnostic value valid when the channel solenoid coil output is off (i.e., 0).

In the "current value" corresponding to Open load[0..7], you can view the diagnostic value of open solenoid valve corresponding to each group of channels of the valve terminal as a whole, a group of channels with normal solenoid valve coils is **0**, and any solenoid valve with an open circuit is not **0**.


Click "+" to expand Open load [0..7], you can view the open diagnostic value of each channel solenoid valve, the value of **1** is the valve open, the value of **0** is normal, as shown in the figure below.




- e. **Short circuit/overtemperature diagnostic**, diagnostic value is valid when the channel solenoid coil output is on (i.e., is 1).

In Short circuit or overtemperature [0..7] corresponding to the "current value", you can view the valve terminal as a whole each group of channels corresponding to the solenoid valve short circuit / overtemperature diagnostic value, there are solenoid valves short circuit / overtemperature is not 0, there is no short circuit / overtemperature is 0.

Click "+" to expand Short circuit or overtemperature [0..7], you can view the diagnostic value of short circuit/overtemperature for each channel solenoid valve, the value of 1 is the solenoid valve short circuit/overtemperature, the value of 0 is not short circuit/overtemperature, as shown in the figure below.



- f. **Channel output control**, if you want to let any one solenoid valve coil output of the valve terminal open, take the first channel as an example, you can click "+" to expand the valve[1...4], in the Bit0 corresponding to the reserve value, write "1", and then press "Ctrl+F7" to write, you can open the first solenoid valve coil channel, the other channels to open the output method is consistent, as shown below.



# 8 FAQ

---

## 8.1 Unable to scan to module

### 1. Check network line connections

Use windows command to ping the IP address of the module, such as ping through, then check the status of the indicator, such as ping can not be, then check the network line connection, such as the network line connection is not abnormal, then the device scanning request acceptance time is set to 60s to scan the module again, such as can be scanned to an unknown device, then the reason is not the module IP has not been assigned, re-assign the IP can be. If you still can not scan to the corresponding module, check the status of the indicator.

### 2. Checking Indicator Status

If the RUN light blinks, the IP address exists. Controller and module may not be in the same network segment, restore the module to factory settings and then reset the IP address; RUN light flashing may also be the module detects duplicate IP addresses in the network, it is recommended to troubleshoot duplicate IP devices and deal with them.

## 8.2 IP address assignment anomaly

### 1. Unable to scan to device under factory setup parameters

Modify the request reception time for module lookup to 60s.

### 2. Timeout for IP address assignment using BOOTP

Click Advanced Settings in IP Address Settings and set the timeout time to 60 s. If this phenomenon occurs when the timeout time has already been set to 60 s, check whether the controller address is in the same network segment as the IP address assigned to the module.

### 3. Loss of assigned IP address after power failure

This is caused by not setting the module to boot with a fixed IP after using BOOTP to assign an IP address.

**4. IP change using rotary switch, no change in IP address**

The IP address setting is out of the specified range or the IP address setting is 0. Verify that the rotary switch settings are as expected.

### 8.3 IP Setting Tool tool does not scan for devices

When the device cannot be scanned using the IP Setting Tool tool, you can try the following methods.

- First, use the cmd command route print to view all the network segments of the routing table, and use the host computer software to set the IP address of the valve terminal so that the IP address is inconsistent with all the network segments of the routing table.
- After an interval of five minutes, re-power on the device, power on 15s, and then scan, such as scanning can not be tried several times.